

	<h2>SenseAnywhere AiroSensor T Model 20-20-30</h2> <p>The SenseAnywhere AiroSensor is a very compact, accurate and robust wireless data logger for temperature and motion. Its ultra low power design allows up to 10 years of operation without maintenance. Perfectly suited for harsh environments like cool trailers, cool boxes, incubators.</p>	
<b>Wireless:</b>		
Frequency	ISM Band, 868 MHz (Region 1) or 915MHz (Region 2)	
Wireless Protocol	SenseAnywhere wireless protocol with automatic service discovery and seamless roaming	
Range	Up to 100m / 300 ft outdoors	
<b>Logging capacity:</b>	15.000 events with date / timestamp	
<b>Battery Life:</b>	Up to 10 years or 1 million messages	
<b>Sensors:</b>		
Temperature	Operating range -40°C to 70°C Accuracy Max. ±0.10°C (0°C to 70°C) Accuracy Max. ±0.15°C (-40°C to 0°C) Long term stability: ≤ 0.01°C /year	-40°F to 158°F ±0.18°F (32°F to 158°F) ±0.27°F (40°F to 32°F) 0.018°F /year
Motion	Accelerometer 3-axis, sensitivity 0g – 16g, programmable	
Reed switch	Detect removal from and insertion into holder	
<b>Compatibility:</b>	EN12830 class 1, storage & transport, Climatic environment type:D CE, EN300328, EN55022	
<b>Mounting:</b>	The holder is pre fitted with very high bond double sided tape and two stainless steel screws are supplied for mounting in very harsh environments or on rough surfaces. Try to avoid mounting on metal surfaces, reinforced concrete walls, inside metal racks or cabinets.	
<b>Casing:</b>		
Material	PC-ABS, easy to clean surface	
Protection class	IP67	
<b>Dimensions:</b>	<b>Sensor</b>	<b>with holder</b>
Height	41mm / 1.61 inch	41mm / 1.61 inch
Width	32mm / 1.26 inch	33mm / 1.30 inch
Depth	22mm / 0.87 inch	24mm / 0.94 inch
<b>Weight:</b>	32g	40g