

			<h3>SenseAnywhere AssetSensor Model 20-10-20</h3> <p>The SenseAnywhere AssetSensor is a very compact and robust wireless data logger for shock and motion. Its ultra low power design allows up to 10 years of operation without maintenance. Perfectly suited as an anti-theft systems for assets like (rent) vehicles, pieces of art, bikes etc. or for monitoring shock on valuable assets.</p>		
Wireless:					
Frequency		ISM Band, 868 MHz (Region 1) or 915MHz (Region 2)			
Wireless Protocol		SenseAnywhere wireless protocol with automatic service discovery and seamless roaming			
Range		Up to 100m / 300 ft outdoors			
Logging capacity:		1.000 events with date / timestamp			
Battery Life:		Up to 10 years			
Sensor:					
Motion		Accelerometer 3-axis, sensitivity 0g – 16g, programmable			
Reed switch		Detect removal from and insertion into holder			
Compatibility:		EN12830 class 1, storage & transport, Climatic environment type:D CE, EN300328, EN55022			
Mounting:		The holder is pre fitted with very high bond double sided tape and two stainless steel screws are supplied for mounting in very harsh environments or on rough surfaces. Try to avoid mounting on metal surfaces, reinforced concrete walls, inside metal racks or cabinets.			
Casing:					
Material		PC-ABS, easy to clean surface			
Protection class		IP68, 24hours @ 1m			
Dimensions:		Sensor		with holder	
Height		41mm / 1.61 inch		41mm / 1.61 inch	
Width		32mm / 1.26 inch		33mm / 1.30 inch	
Depth		22mm / 0.87 inch		24mm / 0.94 inch	
Weight:		32g		40g	