



SenseAnywhere StatusSensor Model 20-11-20

The SenseAnywhere StatusSensor is a reliable and easy-to-implement bin stock supply chain management solution. It is a wireless switch with a visible position indicator that sends replenish requests wirelessly. Its ultra-low power design allows up to 15 years of operation without maintenance. Perfectly suited for keeping track of the stock levels of bins and reordering replenishments. Notifications can be triggered as soon as the BinSwitch is switched. When the network is down the device will log any activities and transmit them as soon as the network is back online again.

Wireless:		
Frequency	ISM Band, 868 MHz (Region 1) or 915MHz (Region 2)	
Wireless Protocol	SenseAnywhere wireless protocol with automatic service discovery and seamless roaming	
Range	Up to 100m / 300 ft outdoors	
Battery Life:	Up to 15 years	
Sensor:		
Reed switch	Detect switch movement in holder	
Compatibility:	CE, EN300328, EN55022	
Mounting:	The holder is pre-fitted with very high bond double sided tape and two stainless steel screws are supplied for mounting in very harsh environments or on rough surfaces. Try to avoid mounting on metal surfaces, reinforced concrete walls, inside metal racks or cabinets.	
Casing:		
Material	PC-ABS, easy to clean surface	
Protection class	IP67	
Dimensions:	Sensor	with holder
Height	41mm / 1.61 inch	51mm / 2.00 inch
Width	32mm / 1.26 inch	33mm / 1.30 inch
Depth	22mm / 0.87 inch	24mm / 0.94 inch
Weight:	32g	46g